



H&E SMITH

Eco-Glazed Brick Slips Fixing Instructions



(This guidance applies to general brick slip installations)

1. Substrate

Ensure the surface to be covered is clean and free from loose debris and grease.

2. Adhesives

2.1 Cement based adhesive

These are relatively straightforward to use. They have good grab strength and this reduces the need for support. They tend to cope with wide application temperature ranges. They work on all surfaces except, plastic metal and glass. There are many manufacturers but recommended companies include Mapei and Ardex.

Mix the adhesive to the guidance on the bag. Add water as indicated on the bag and mix thoroughly with an agitator. Apply as if you are tiling the wall using a comb to achieve a ribbed effect.

2.2 Epoxy based adhesive

These are mostly supplied as 2 part mixes and have very high grab strength. They often need support until set.

Recommended companies include Apollo Adhesives, Structural Adhesives and Kommerling.

3. Fixing

Our brick slips are produced using traditional methods and a degree of shade variation is inherent and desirable. We recommend that before fixing it is essential to lay them out in good light, to ensure an acceptable blend of colour and size. Glazed brick slips may craze with time, therefore in this respect no guarantee can be given.

Start at the bottom ensuring that the first course is level. For the 2nd and subsequent courses stagger joints to achieve the bonding pattern desired.

If necessary use a 10mm spacer to support the next course and make sure the brick slip stays in place until the adhesive has cured. Spacers can be made from fillets of wood or strips of plaster board.

4. Cutting

Slips can be cut using the following methods:

- a) Break with a hammer and bolster. (The slips will not always break cleanly)
- b) Use of an electric tile cutter.
- c) Use of a small angle grinder with cutting disc.
- d) Using a clipper saw.

Always use gloves to protect from cuts and eye protection in case chips and dust cause irritation.

5. Pointing

Allow sufficient time for the adhesive to set. This is likely to be 24-48 hours depending on the adhesive type and the ambient temperature.

Point the finished cladding using standard sand/cement mortar mix. Coloured mortars may be used to achieve different finishes. Strike the joint using a suitable tool as would be used to finish normal brickwork.

